产品选型说明 Product selection instructions

专注植物灯级连控制器 有线、无线、远程控制 定向开发



深圳市祥瑞万嘉科技有限公司

Shenzhen XRWJ Power Technology CO.,Ltd.

http://www.xrwja.com/

Unified Services Hotline 统一服务热线: 13480708216 (商务) 13088834216 (技术)

Address: 7th Floor, No.551, Jiuweizhoushi Road, Hangcheng Street, Baoan District, Shenzhen

地址:深圳市宝安区航城街道九围洲石路 551 号 7 楼

控制器产品类别及连接说明:

1、主控

主控款式说明							
名称	输出信号路数	连接方式	特点				
旋钮款数字控制器	1-3 路可选	有线连接(见连接方式1)	信号无衰减,无限级连				
显示屏+按键款	1-3 路可选	有线连接(见连接方式 2)	定时开关、亮度、场景自定义、 温湿度检测等				
显示屏+按键+蓝牙款	1-3 路可选	无线控制+有线连接(见连 接方式 2)	APP 控制+手动两端控制、自动 同步,定时 40 组、断电记忆、 开关、亮度、场景自定义 可选配网关远程控制				
旋钮+蓝牙款	1-3 路可选	无线控制+有线连接(见连 接方式 3)	APP 控制+手动旋钮控制可自由 切换,定时 40 组、断电记忆、 开关、亮度、场景自定义 可选配网关远程控制				

2、分控

分控款式说明					
名称	输出信号	连接方式	特点		
旋钮款电阻控制器	1 路	有线连接	可控制 0-10V、PWM、电阻三合一驱动(不能级 连)		
旋钮款数字控制器	1-3 路可选	有线连接(见连 接方式 1-2)	信号无衰减,无限级连		
内置款数字控制器	1 路	有线连接(见连 接方式 1-2)	信号无衰减,无限级连(可按结构定制)		
接力式 MESH 蓝牙 款	1 路	手机 APP 无线控制 无线连接(见连接方式 4)	APP 控制、无需主控,自定义分组、编组联控、 定点控制、定时开关、亮度、场景自定义(定时 8 段) 可选配蓝牙定时器(定时 40 组、断电记忆、) 可选配网关远程控制、服务器定时,定时不受限)		


3、蓝牙定时器

名称	连接方式	特点
蓝牙定时器	无线连接	群组定时、40 组定时、断电记忆、定时开关、亮度、场景自定义

4、网关

名称	连接方式	特点
WIFI 网关	APP 无线连接	接连 WIFI, 远程控制、服务器定时、定位当地日出日
		落控制灯具、定时不受限
WAN 网关	APP 无线连接	连接 WAN 以太网,远程控制、服务器定时、定位当
		地日出日落控制灯具、定时不受限
4G 网关	APP 无线连接	插入SIM卡,远程控制、服务器定时、定位当地日
		出日落控制灯具、定时不受限






Connection method 1:

The sub-controller is the main control, the sub-control knob is set to the cascade position, and all dimmers behind it are controlled by the No. 1 dimmer; when the No. 2 dimmer is directly adjusted, the control is connected to No. 2 All dimmers behind the dimmer, No. 1 is out of control at this time;

连接方式1:

由分控当主控,将分控旋钮钮到级连位置,由1号调光器控制接到其后面的所有调光器;当直接调节2号调光器时,则控制接到2号调光器后面的所有调光器,此时1号不受控制;




Connection method 2:

Set the sub-control knob to the cascade position, and the external main control dimmer will control all the dimmers connected behind it; at this time, adjusting the sub-control is invalid.

连接方式2:


将分控旋钮钮到级连位置,由外接主控调光器控制接到其后面的所有调 光器;此时调节分控无效。



Connection method 2:

Set the sub-control knob to the cascade position, and all the dimmers connected behind it are controlled by the external Bluetooth + manual master dimmer; at this time, the adjustment of the sub-control is invalid. 连接方式3:

将分控旋钮钮到级连位置,由外接蓝牙+手动主控调光器控制接到其后面的所有调光器:此时调节分控无效。



Connection method 3:

Pure wireless version, mobile APP control, overall control, group control, fixed-point control, without master control 连接方式4:

纯无线版本,手机APP控制,整体控制、分组控制、定点控制,可无需主控

APP 下载说明:

- 1、该 APP 支持 Android+ios
- 2、下载二维码



RippHome

详见使用操作说明